



4RUNNER

TOYOTA

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
2006-08	Winch Bar	Airbag Approved, Recessed Indicators, Recessed Fog Lamps ⁵	9.5xp, HS9500, XD9000, M8000	3421210
2003-05	Winch Bar	Airbag Approved, Recessed Indicators, Recessed Fog Lamps ⁵	9.5xp, HS9500, XD9000, M8000	3421200
1986-95	Winch Bar	Recessed Indicators ² , Tow Points, Black	XD9000, M8000, M6000	3414070 ¹
1984-85	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3414090

¹ Fitment of bar to 4Runner models may require modifications - contact ARB for details.

² 1986-89 Pickups and 1986-95 4Runners require OE indicators from 1989-94 Pickup - **not supplied**.

³ ARB bars #3921030 & 3421010 measure 72" wide and suit models with wide fender flares.

⁴ ARB bar # 3423020 measures 68" wide and suits models with narrow fender flares.

⁵ Optional on this model - ARB part no. 9249FCK

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
ALL	ALL	800XSD, 900XS, 900HID, 960S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
1989-94	3.0L, V6 Snorkel - needs modifications	SS130HF
1984-88	2.0L/2.2L Snorkel - needs modifications	SS65HF

Refer to www.safari4x4.com.au for details.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Year/Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
2003-08 Models	Front	Light Load - Stock weight - no Bar or Winch	Spring	1.0"	2	OME884 ¹
			Shock		2	N140S
		Medium Load - with Bar or Winch only (70-180lbs)	Spring	2.0"	2	OME885 ¹
			Shock		2	N140S
			Spring	2.5"	2	OME886 ¹
			Shock		2	N140S
	Rear	Medium Load	Spring	2.0"	2	OME895
			Shock		2	N141
		Heavy Load (330lbs to GVW)	Spring	2.0"	2	OME896
					2	N142
Optional	Front Trim Spacer 5mm					OME95PF5
	Lower Shock mount stone guard (recommended)			2		OME661

¹ Important: OME front coils can only be installed with OME Nitrocharger strut and coil seats.

OLD MAN EMU SUSPENSION PRODUCTS

1996-02 Models	Front	Stock/Light Load (0-110lbs)	Spring	1.25"	2	OME880 ¹	
			Shock		2	N91SC	
	Rear	Heavy Load (110-240lbs)	Spring	1.25"	2	OME881 ¹	
			Shock		2	N91S	
		Medium Load	Spring	2.0"	2	OME906	
			Shock		2	*N86/N86C	
		Heavy Load (330lbs to GVW)	Spring	2.5"	2	OME890	
			Shock		2	N86	
	Heavy Constant Load (660lbs to GVW)	Spring	3.0"	2	OME891		
				2	N86		
	Optional	Front Trim Packer 5mm					OME95PF5
		Rear Trim Packer 5mm					OME80PF05
Rear Trim Packer 10mm					OME80PF10		

¹ Important: OME front coils can only be installed with OME Nitrocharger strut and coil seats.

*Firmer shock.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Year/Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
IFS / Rear Coil Spring 1990-95	Front	Stock/Light Load	Torsion Bars		1	303003 ¹
			Shock		2	N98
	Rear	Medium Load (0 to GVW)	Spring	1.50"	2	OME900
			Shock		2	N72F
		Heavy Constant (330lbs to GVW)	Spring	1.50"	2	OME901
			Shock		2	N72F
Installation	Steering Damper				1	OMESD33

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

IFS / Rear Leaf Spring Pre 1990	Front	Stock/Light Load	Torsion Bars		1	303003 ¹	
			Shock		2	N98	
	Rear	Medium Load (0lbs to GVW)	Spring	2.0"	2	CS009R	
			Shock		2	*N85/N94	
		Heavy Constant (440lbs to GVW)	Spring	2.25"	2	CS010R	
			Shock		2	N85	
	Installation	Rear Leaf Spring Bushing Kit				2	OMESB6
		U Bolts				4	OMEU53
		Steering Damper				1	OMESD33
	Optional	Greaseable Shackle Kit				1	OMEGS3
Greaseable Pin Kit				1	OMEGP3		
Rear Extra Leaf					D5XL		

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² Install OE caster wedges from OE spring pack onto OME springs. Ensure wedges are fitted as per original position.

³ Compare original spring pack height to OME spring pack to determine whether OMEU53 or OMEU53B U bolts are required.

⁴ Extra leaf can be fitted for heavier constant load carrying ability.

OLD MAN EMU SUSPENSION PRODUCTS

All Leaf Springs 1984-85	Front	Stock/Light Load (0-110lbs)	Spring	2.0"	2	CS008FA/B
			Shock	2.0"	2	N84
		Heavy Load (110-240lbs)	Spring	2.0"	2	CS009FA/B ¹
			Shock	2.0"	2	*N93/N84
	Rear	Medium Load (0lbs to GVW)	Spring	2.0"	2	CS009R ⁷
		Post '84	Shock	2.0"	2	*N85/N94 ⁵
		Pre '84	Shock	2.0"	2	*N89/N95 ⁵
		Heavy Constant (550lbs to GVW)	Spring	2.25"	2	CS010R ⁷
		Post '84	Shock	2.25"	2	N85 ⁵
		Pre '84	Shock	2.25"	2	N89 ⁵
Installation	Front Spring Bushing Kit				2	OMESB5
	Rear Spring Bushing Kit				2	OMESB6
	Front U Bolts				1	OMEU52 ³
	Rear U Bolts				4	OMEU53
	Rear Anti Inversion Kit (Post '84)				1	FK13 ⁵
	Rear Anti Inversion Kit (Pre '84)				1	FK09 ⁵
	Steering Damper				1	OMESD21
Optional	Front Greasable Shackle Kit				1	OMEGS4
	Rear Greasable Shackle Kit				1	OMEGS3
	Greasable Pin Kit				2	OMEGP3
	Front Fitting Kit				1	FK03/FK10 ⁵
	Front Extra Leaf					D17XL ⁶
	Rear Extra Leaf					D5XL ⁶
	Rear Trim Spacer					TP04 ⁷

¹ A/A spring fitment may be needed on some vehicles for trimming purposes.

² 1985-89 automatic 4Runner requires modified rear springs. Contact OME for details.

³ Shock selection N89/N95 for medium and N89 for heavy applications applies to vehicles up to 1984 due to a 16mm eye and shorter open and closed lengths. Post 1984 vehicles with 19mm eye use N85/N94 for medium applications and N85 for heavy applications.

⁴ OMEU52 is required when fitting CS009FA/B or CS008FA/B springs because original U bolt will foul drag link on full droop. Refer to OME Fitting Manual.

⁵ Pick up models may require an FK03 (saddle correction plates) if the spring seats are distorted. FK10 must be fitted to all models used continually off road. Refer to OME Fitting Manual.

⁶ Extra Leaf can be fitted for heavier constant load carrying ability.

⁷ A trim spacer may be required to trim vehicle. Only to be used on rear springs. Important: Install leaf springs with military wrap at the fixed end.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

Year	Axle	Description	Shaft	Spline	Ratio	Part No.
2003-08	Front	8" dia. RG, IFS, 53mm bearing ID	33 (1.31")	30	3.91 & UP	RD111
2003-08		8" dia. RG, IFS, 53mm bearing ID	33 (1.31")	30	3.73 & DN	RD121
To 2002		8" dia. RG, 10 bolt, live axle	33 (1.31")	30	ALL	RD132
To 2002		7.5 dia. RG 10 bolt, IFS	28 (1.1")	27	ALL	RD90
1984-88	Rear	4 cylinder, 45mm carrier bearing	33 (1.31")	30	ALL	RD132 ¹
1988-08		V6, 4WD, 50mm carrier bearing	33 (1.31")	30	ALL	RD132 ²
1988-08		V6,2WD, 45mm carrier bearing	33 (1.31")	30	ALL	RD132 ^{1,2}

¹ Late model 50.00mm (1.969") ID bearings must be used with this specific application. (ARB Part No. 160116)

² Suits open differential carriers only