



TOYOTA / LEXUS

LAND CRUISER 80 SERIES & LEXUS 450

ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
1990-97	Winch Bar: 80 Series	Recessed Indicators, Tow Points, Black	M12000, M10000 ¹ , XD9000 ² , M8000 ²	3411050
1990-97	Bull Bar: 80 Series	Recessed Indicators, Tow Points, Black	N/A	3211050
1996-97	Winch Bar: LX450	Recessed Indicators, Tow Points, Black	M12000, M10000, XD9000	3411050

¹ Only available through ARB USA - ARB part no. US20801

² Fitment of Warn XD9000 & M8000 winch requires special spacer kit - ARB part no. 3500050.

IPF LIGHTS & LIGHTING ACCESSORIES

Year	Model	Recommended Lighting
1990-97	80 Series	800XSD, 868CS, 968CS, J-01
	LX450	800XSD, 868CS, 968CS, J-02

ARB SIDE RAILS & STEPS

Year	Model	Description	Part No.
1990-97	GXL & VX	One-piece side protection rails and steps to suit <u>models with fender flares</u> (requires ARB bumper for mounting), Black	4411010
1990-97	Std, DX, RV & Advantage	One-piece side protection rails and steps to suit <u>models without fender flares</u> (requires ARB bumper for mounting), Black	4411030

ARB REAR PROTECTION BARS

Year	Type	Item	Part No.
1990-97	LC80 & LX450	Deluxe Rear Bar, Grey	5611010 ¹
		LHS blank cover panel, Grey	5700031 ²
		RHS blank cover panel, Grey	5700032 ²
		LHS tire carrier, Grey	5711011 ²
		RHS tire carrier, Grey	5711012 ²
		LHS jerry can holder, Grey	5711021 ²
		RHS jerry can holder, Grey	5711022 ²
	Optional	Antenna mount LHS	5711031
		Antenna mount RHS	5711032
		LHS camp light	5711041
		RHS camp light	5711042
		Hilift mount for wheel carrier only	5700060
		Reversing light kit	5700070
		Axe and Shovel mount (mounts on wheel carrier)	5700080

¹ A left or right hand side cover panel must be used for installation if tire carrier or jerry can holder is not purchased.

² Customer can use a combination of blanks, tire carriers, or jerry can holders for a complete installation. **A minimum of 3 separate part numbers will be required for this bar to mount to the vehicle.**

*** Contact ARB with any questions before ordering

SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
1990-97	All models	SS81HF

Refer to www.safari4x4.com.au for details.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
80 Series & LX450	Front	Stock/Light Load (0-110lbs)	Spring	2.0"	2	OME851
			Shock		2	*N73/N70
		Heavy Load (110-250lbs)	Spring	2.0"	2	OME850
			Shock		2	N73
		Low Height Heavy Load (110-250lbs)	Spring	.25"	2	OME861
			Shock		2	N73
	Rear	Medium Load (0lbs to GVW)	Spring	2.0"	2	OME860
			Shock		2	*N74E/N71E
		Constant Load (440lbs to GVW)	Spring	2.0"	2	OME863
			Shock		2	N74E
		Heavy Constant (880lbs to GVW)	Spring	1.50"	2	OME864
			Shock		2	N74E
	Low Height Medium Load (0lbs to GVW)	Spring	.75"	2	OME862	
		Shock		2	*N74E/N71E	
Installation	Caster Kit			1	OMECA77B ¹	
	Steering Damper			1	OMESD24	
Optional	Rear Shock Stone Guard			1	OME661 ²	
	Front Trim Spacer 5mm				OME80PF05 ³	
	Front Trim Spacer 10mm				OME80PF10 ³	
	Rear Trim Spacer 5mm				OME80PR05 ³	
	Rear Trim Spacer 10mm				OME80PR10 ³	
	Front LTR Shocks			2	LTR01F ⁴	
	Rear LTR Shocks			2	LTR01RR/L ⁴	

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
80 Series & LX450	Also Available	Front Extended Height Coil Springs			2	OME850J ⁵
		Front Extended Length Shock			2	N73L ⁵
		Rear Extended Height Coil Springs			2	OME863J ⁵
		Rear Extended Length Shock			2	N74L ⁵

¹ OMECA77B Caster Kit will increase caster by 2 degrees. Caster angle will be affected when raising the vehicle. Check manufacturer's specifications to determine if OMECA77B is required.

² OME660 lower shock mount stone guard is recommended fitment to rear shocks to protect against severe stone peppering encountered on loose road surfaces.

³ Trim spacers may be required to trim the vehicle to a maximum of 15mm per coil. Packers must be installed on the top end of coil spring.

⁴ LTR Remote Reservoir shock absorbers are for competition use and require regular maintenance.

⁵ OME850J/863J coils and N73L/74L shocks should be installed together, although they do not comprise a kit. Fitment of N73L/N74L shocks requires mandatory installation of .75" (20mm) Front and 1.25" (30mm) Rear bump from bottoming out under full compression. These bump stop spacers are not available from OME and will need to be sourced by the installer.

*Firmer shocks

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1990-97	Front	10 bolt, full floating	33 (1.31")	30	ALL	RD132
1990-92 ²	Rear	12 bolt, semi floating	33 (1.31")	30	ALL	RD124 ¹
1993 On		12 bolt, full floating	33 (1.31")	30	ALL	RD33

¹ Must use late model 50.00mm (1.969") ID bearings with this locker for this specific application (ARB Part No. 160116)

² Only vehicles made in North America.

³ RD132 superceeds RD23 March 2007

ARB ROOF RACKS

<u>Models</u>	<u>Recommended Roof Racks</u>	<u>Part No.</u>
80 Series & LX450	87x49" Rack with Mesh Floor	3800010M
	87x49" Rack without Mesh Floor	3800010
	87x49" Touring Rack for Roof Top Tent	3800200
	Fitting Kit for 87x49" racks	3700050
	73x49" With Mesh Floor	3800020M
	73x49" Without Mesh Floor	3800020
	Fitting Kit for 73x49" racks	3700050
	43x49" With Mesh Floor	3800030M
	Fitting Kit for 43x49" racks	3700060
	Wind Deflector for 49" wide Roof Rack	3700310
	Hi-lift Jack and Shovel holder for ARB Roof Rack	K6202