



PATHFINDER

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
2000-02	Sahara Bar	Airbag Approved, Recessed Fog Lamp Provision ¹ , Urethane Buffers. Tow Points ² . Grev	HS9500, XD9000, M8000, M6000	3938020
1987-95	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3438040

¹ Optional on this model - ARB part no. 9381FCK

² Utilizes original equipment tow points.

IPF LIGHTS & LIGHTING ACCESSORIES

Year	Type	Recommended Lighting
2000-02	3938020	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01
1987-95	3438040	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
1986-97	D21, 2.7L, Diesel, Left Side Mount Refer to www.safari4x4.com.au for details.	SS700HF

OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.		
2005-06 R51 Models	Front	Stock/Light Load (0-90lbs)	Spring	1.0"	2	OME607		
			Shock		2	N183S		
	Rear	Medium Load (90lbs-220lbs)		Spring	1.0"	2	OME608	
				Shock		2	N183S	
		Medium Load (0lbs to GVW)		Spring	1.0"	2	OME609	
				Shock		2	N184	
		Constant Heavy Load (440lbs+)		Spring	1.0"	2	OME610	
				Shock		2	N184	
		**OE plastic stone shield must be refitted onto N183S and a 4-wheel alignment must be carried out after fitment of OME suspension.						
		1996-04 R50 Models	Front	Stock/Light Load (0-60lbs)	Spring	.50"	2	OME921
Right Side	Shock				1	N143S		
Left Side	Shock				1	N144S		
Front	Medium Load (50-110lbs)			Spring	.50"	2	OME923	
				Shock		1	N143S	
	Left Side		Shock		1	N144S		
Front	Heavy Load (110-220lbs)			Spring	.50"	2	OME928	
				Shock		1	N143S	
	Left Side		Shock		1	N144S		
Rear	Medium Load (0lbs to GVW)		Spring	.50"	2	OME922		
	Medium Load (to 1/1999)		Shock		2	*N61/N61C		
	Medium Load to (2/1999)		Shock		2	*N104/N104C		
1987-95	Front		Stock/Light Load (0-110lbs)	Spring			N/A ¹	
				Shock		2	N26F	
	Rear	Medium Load (0lbs to GVW)		Spring	.75"	2	OME920	
				Shock		2	*N42/N89	
	Installation	Steering Damper				1	OMESD35	

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² It may be necessary to slightly increase the clearance in the front wishbone to allow shock absorber to fit. Do not modify shock absorber.

*Firmer shock.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1987 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107
1987 On	Rear	H233B, 31 spline, 6 Cyl.	32.4 (1.20")	31	ALL	RD09 ²
		H233B, 33 spline, 6 Cyl.	33.3 (1.31")	33	ALL	RD24 ²
1986-97	Rear	C200, 29 spline, 4 Cyl.	30.4 (1.20")	29	ALL	RD107 ^{1,2}

¹ Only suitable for differentials with 12mm crown wheel bolts.

² **Refer to dealer or check spline count to determine axle type.**